

LATERAL MAGNETIC MAGAZINE POUCH

MANUAL

English



If you need any support with your product
please contact us at:

productsupport@gugaribas.com.br

ENGLISH VERSION

INTRODUCTION

The lateral magnetic magazine pouch is one of our most traditional and well-known products, principally because it is extremely resistant and durable, and is suitable for all types of magazine. Follow the steps in this manual in order to get the most out of your new product. For your own safety, follow the instructions carefully.

To access information about our
manuals on-line, visit:
<http://gugaribas.com.br/en/manuals>



LATERAL MAGNETIC MAGAZINE POUCH PARTS:

1. Magnet
2. Compact Hanger
3. Allen Key (3mm)

1. FIXING THE MAG POUCH ON THE HANGER AND ADJUSTING THE HEIGHT

ATTENTION!

You are dealing with a strong, powerful magnet. Keep it away from electronic and metallic devices. If you have more than one magnet, ensure that they are not close to each other, and that they are not getting stuck together eventually hurting your hand.

You received GR Company's Lateral Magnetic Magazine Pouch!

The hanger is also compatible with the Standard Magazine Pouch!*

To replace your Magnetic Pouch by the Standard is easy:

- 1) Loosen up the tightness disc that attaches the Magnetic Magazine Pouch to the hanger (pic 01)
- 2) Slide up the Magnetic, withdrawing it from the hanger (pic 02).
- 3) Insert the Standard sliding it down (pic 03)
- 4) Tighten up the tightness disc that attaches the Standard Magnetic Pouch to the hanger (pic 04).


*Magnetic also adjustable to the old version of the hanger.



2. ADJUSTMENT IN THE BELT



- 1) Loosen the tighness disc and remove the magnet. (pic 06 & 07)
- 2) Using the Allen Key, remove the hanger's screws (pic 08 & 09)
- 3) Put the body (A) on the outside of the belt with the opening turned up.
- 4) Using the smaller screw (P2), join the superior support insert (B), regarding the limit of the belt's edge as shown in the pictures 10 and 11..



- 5) Tight up softly the screw using the Allen Key, just for the body (A) to be placed not surpassing the belt's edge. (pic 11)
- 6) Join the inferior regulation insert (C) to the body (A) with the bigger screw (P1) then regulate its position to adapt to the belt's width. After that tight up the screw softly (pic 11, 12 & 13)
- 7) Place the hanger at your favorite position in the belt. (pic 13)



8) Finish tightening the screws P1 & P2 (pic 13).

9) Slide your Magnetic Magazine Pouch through the opening, adjusting the height and firmness tight the disc up (pic 14 & 15).

10) Done! Your Magnetic Magazine Pouch is ready to be used! (pic 16).



CONGRATULATIONS!

Your Magnetic Magazine Pouch is ready to be used.

